


Expandable PIR SMS Security

S-PIR & S-PIRw (expandable)



Overview

The S-PIR range is a simple to install security system which sends SMS text message alerts directly to your mobile phone when it detects an intruder. A compact PIR movement detector it can be armed/disarmed just by calling it from an authorised number.

Features

- SMS Alarm text can be sent to up to 5 recipients
- Customise the SMS message "Office Alert", "Garage", "Boat" etc
- Arm/Disarm from your mobile phone with confirmation
- Power failure/unplugged alert SMS
- Configuration via PC, SMS or remotely via GPRS
- Microphone - listen in remotely
- Portable - can be moved when you move.
- No land line requires - uses any main GSM mobile network
- Low running costs - price of text messages
- Regular status message - system working
- Schedule arm/disarm times
- **S-PIRw** version can connect to 16 local wireless slave sensors, extra room PIR sensors, door sensors etc to build up a complete building security system. Slave range 30m (indoor). Slave devices are battery powered (included) and alerts can be customised to inform you which room/door/zone has been breached.

Ordering



S-PIR

Non-expandable
PIR SMS Alert
Alarm Unit



S-PIRw

Expandable PIR
SMS Alert Alarm
Unit



S-PIRd

Magnetic Door/Window Switch



S-PIRs

PIR slave sensor

| Type | Description | Part Number |
|------------------|--|-------------|
| S-PIR | Standalone S-PIR unit with UK plug-in power supply & UK PAYG SIM card (unregistered) | SME-SPIR |
| S-PIR Expandable | Standalone S-PIR unit with UK plug-in power supply & UK PAYG SIM card (unregistered) | SME-SPIRW |
| PIR Slave Sensor | Battery powered slave PIR sensor for use with main S-PIRW hub unit. | SME-SPIRS |
| Door Sensor | Battery powered slave door/window sensor for use with main S-PIRW hub unit. | SME-SPIRD |